
Trigger Tower Monitoring Cover


Trigger Tower Monitoring Cover


RUN2B L1 CAL TRIG BLS TO ADF PATCH PANEL
Patch Panel Card 1
P1
P2
J9
J10
J19
J20
J1 J2 J3 J4
J5 J6 J7 J8
J11 J12 J13 J14
J15 J16 J17 J18
E H
GND
SIGNAL
Trigger Tower Monitoring
Patch Panel Card 2
P1
P2
J9
J10
J19
J20
J1 J2 J3 J4
J5 J6 J7 J8
J11 J12 J13 J14
J15 J16 J17 J18
E H
GND
SIGNAL
Trigger Tower Monitoring