
Trigger Tower Monitoring Cover
Trigger Tower Monitoring Cover
RUN2B L1 CAL TRIG BLS TO ADF PATCH PANEL
Patch Panel Card 1
Trigger Tower Monitoring
Patch Panel Card 2
Trigger Tower Monitoring
J9
J10
J19
J20
J1
J2
J3
J4
J5
J6
J7
J8
J11
J12
J13
J14
J15
J16
J17
J18
Paint Keep Out Area
Iridite finish only
Paint keep out Area
Iridite finish only